

EC Flash SOP for Windows

Document Revision: v1.5

Issue Date: 2022/11/09

Author: Helena.Zeng

1. Copy folder including all files to your machine.
2. Boot into windows and enter "WIN" folder, double click "IFU_XE.exe".

名称	修改日期
IFU_XE.exe	2022/8/5 14:26
inpout32.dll	2022/8/5 14:26
ITEECNM.BIN	2022/11/3 16:14
uiset.ini	2022/11/9 11:01

3. Updating



4. After finish flashing,please Shutdown the system and unplugAC by manual.
5. replug AC and press power button boot into bios setup to check EC version.
6. Flash finished