


SPECIAL FUNCTION OF THE MULTIMEDIA KEYS

This Notebook is supplied with an additional multimedia function that will enable you to play photo slideshows, video DVDs, audio CDs or MP3 files by pressing a key, without having to start the Windows® operating system. Read how you can use this 'Linux Power Cinema' program in the following section.*

SWITCH POWER CINEMA ON AND OFF



You will switch the Notebook on and off with the help of the On/Off Switch (9). The Windows operating system will be started or shut down again at the same time.

Please proceed as follows to operate the Linux Power Cinema application:

1. You will start the Linux Power Cinema application with the Playback / Pause Key (1), when the Notebook is switched off. The user interface, which you will be able to operate with the aid of the remote of the multimedia keys, will appear after a short time. Refer to the comprehensive operating instructions of the Notebook for a more precise description of the keys.
2. Now, you will be able to insert a DVD or a CD and start the desired playback with the corresponding Menu Point.
3. It is possible to leave the application in three ways:
 - a. Press the On / Off Switch (9) of the Notebook briefly,
or
 - b. Press the Power Button on the remote
or
 - c. Select the 'Switch Off' Menu point.

SYSTEM RECOVERY

You will be able to return both Linux and Windows® to the state at delivery with the Recovery Disk supplied. Please proceed as follows:

1. Open the tray by means of the emergency removal opening on your optical drive. Please read more precise information about this in the operating instructions supplied with your Notebook.
2. Insert the Recovery Disk and start the Notebook.
3. You will be able to choose between Linux [enter 1 and Enter] or Windows® [enter 2 and Enter] through the Boot Menu. Windows will start the Windows® operating system after a short time if you do not make an entry.
The Windows® Recovery Function will offer you various possibilities.
The Linux Recovery Function will only offer complete recovery. There will be no user data in the Linux partition.
4. The disk will be ejected and the Notebook will shut down after the recovery.
☞ The recovery process will be broken off if you have partitioned the hard drive, in whatever way, and have not left any space or too little of it.

*The card reader and the TV tuner card will not be supported here.