Making a WLAN connection

A connection to the Internet is necessary in order to use this product to its full extent. This can be through a network cable or through WLAN. Proceed as follows to set up a WLAN connection:

- Make sure that the WLAN function is switched on. Check the nidicator light for this. Refer to the detailed instruction manual for the correct key combination.
- 2. Click on the icon at upper left corner of the screen.
- 3. Click on the WLAN network to which you want to connect.
- 4. If a new window appears requesting authentication, enter the required WLAN key or password and click **Connect**.

Installing a new version of MEDION® FastBoot

- 1. Download the current version from the Medion website.
- 2. Start the VR-pulse Installer in the Windows Control Panel.
- Uninstall the current version of the program by clicking the Uninstall button.
- 4. Click **Install** to install the new version.
- 5. All data, settings and downloaded updates will be deleted and will need to be re-installed. After installing a new version, optimizations will be performed during the first re-start, which will make the startup time longer. Subsequent restarts will be not be affected.

Restore to factory default

You can restore MEDION® FastBoot to the default settings by clicking **Restore to factory default** in the MEDION® FastBoot Control Panel.

Warning!

All your current settings will be reset to the factory defaults and you have to download the upgrades like Google Chrome & VLC-player once again.

Provision of the source code and licence conditions

You will find a machine-readable source code of the components described on the disk supplied. Please pay attention to the copyright notice, the guarantee terms and the licensing conditions that are attached to the source code.

MEDION® FastBoot



The MEDION® FastBoot system enables fast and easy access to the Internet browser, email and social networks without having to carry out a complete system start.

Warning!

You must complete the initial **Set Up Windows** procedure for the Windows® operating system before starting MEDION® FastBoot for the first time. See the corresponding section under **Getting Started** in the **Instruction manual**.

Starting MEDION® FastBoot

Information

Read this section through completely before you switch on the Notebook. The option to start MEDION® FastBoot appears quickly, and only briefly, so you are likely to miss it otherwise.

Start the application as follows:

- 1. Switch on the notebook with the On /Off switch.
- Rapidly tap the F9 key 2-3 times when you see the message Press F9 for Medion FastBoot OS.
- 3. MEDION® FastBoot will now start.

Warning!

Settings to optimize the function of MEDION® FastBoot will run in the background when it has been started for the first time. This process will last several minutes and will only take place after the first start. **Do not switch off** the Notebook during this process.

- 4 - MSN 4003 8815 - 1 -

Configuring MEDION® FastBoot

To configure MEDION* FastBoot:


- 1. Open the **Control Panel** by clicking on the icon with the screwdriver and pliers.
- Select Preferred OS ⇒ FastBoot in order to establish FastBoot as the standard operating system, or select Preferred OS ⇒ Microsoft Windows, in order to establish Microsoft Windows as the preferred operating system.
- 3. Your notebook will start automatically with the preferred operating system at the next start.

Note

If FastBoot is selected as the preferred OS it will no longer be necessary to start MEDION® FastBoot with the aid of the F9 button. You can naturally also make the same settings with the Microsoft Windows, as described above, under the MEDION® FastBoot option.

User interface

The various icons along the bottom of the screen allow you to check your email, surf the internet, chat on social networks, and more.



1 En	nail ap	plica	tion
------	---------	-------	------

8 Open Facebook in browser

2 Internet browser

9 Open Twitter in browser

3 VLC Player^{*}

10 Calendar (optional)

4 File browser

11 Control Panel

5 Picture Viewer

12 Date / time setting

6 Skype

13 Battery status indicator

7 Application for different Instant Messenger services 14 Exit MEDION® FastBoot

Information

Some applications offer updates. A corresponding message will appear on the screen.

Information about operation

- You can modify various power saving settings in Control Panel, Power Management. Switch the Notebook off to avoid unnecessary power consumption if not using MEDION FastBoot for an extended time.
- Bluetooth and USB 3.0 are not supported by MEDION® FastBoot™.
- Compatibility with all USB media is not guaranteed; external optical drives are not supported, for example.
- The playing back of copy-protected content is not supported.

Switching off MEDION® FastBoot

You can switch off MEDION® FastBoot either by means of the button or by means of the on /off switch of the Notebook.

Switching the Language

Medion® FastBoot is set to English language by default.

- 1. A selection window will open at the first start and you will be able to select your language.
- 2. You can change the settings at any time by means of the **Control Panel**, by clicking on the icon with the screwdriver and pliers.



3. Close the **Control Panel** Window by clicking cross at the upper right corner.

Attention!

The default language (English US) matches the physical keyboard layout. Keyboard settings for other languages match physical keyboards from those countries and may differ from the Notebooks physical layout.

Special symbols such as @, +, -, etc. may require using different keys.

The most current version of the VLC Player will be downloaded and installed after the conditions for licensing and use have been accepted.